

Piezotech Processing's guides

- How to measure -


Charge sensors.

Concepts:


A charge sensor generates on its surface equal electric charges of opposite sign when it is stimulated by a mechanical force (piezoelectric effect) or a variation of temperature (pyro electric effect).

Equivalent diagrams:

A piezo- pyro- electric sensor can be modelled by one of the following equivalent diagrams:



Thevenin equivalent diagram:
The electromotive force $e = Q/C_0$ is in series with a capacitor C_0 .



Norton equivalent diagram:
The current source $i = \frac{dq}{dt}$ is in parallel with a capacitor C_0 .

Mode of operation:


When using a piezo- pyro- electric sensor, the measured signal strongly depends on the conditions of experimentation. It is possible to measure a proportional signal, or to its derivate. The limit of these operation modes is given by the cut-off frequency of your instrumentation chain.

Signal conditioning

Direct connection:

By connecting your sensor directly to your amplifier, oscilloscope, or DAC (data acquisition card) it must be kept in mind that external impedances may have a critical influence on the signal you will measure. In order to determine the said influences, the involved impedances (from the sensor, cable and measuring instrument input) are modelled as follows:

Equivalent diagram of a direct connection of a sensor.



Further analysis of the diagram shows a high-pass filter behaviour, for which the cut-off frequency is given by:

$$f_c = \frac{1}{2\pi \cdot R_{\text{eq}} \cdot (C_{\text{eq}} + C_i)}$$

When $f \gg f_c$ the measured signal is directly proportional to the generated charges:


$$v_{IN}(t) = -\frac{q(t)}{C_{eq} + C_f}$$

Charge transducer:

In order to drastically limit the influence of external impedances, the use of a charge transducer is recommended. The operating principle is based on the use of an external capacitor C to store the generated charges. A charge transducer may be also called a charge-voltage converter.

When $f \ll f_c$ the measured signal is proportional to the derivate:

$$v_{IN}(t) = R_{eq} \cdot \frac{dq(t)}{dt}$$



transducer

As shown in the diagram, we consider the operational amplifier as ideal. The differential voltage between its inputs is null, so the current i generated by the sensor is driven to the feedback capacitor C . In order to prevent saturation of the output by parasitic influences, a parallel resistor R must be added to the feedback capacitor.

Such a circuit has a high-pass filter behaviour, for which the cut-off frequency is given by:

$$f_c = 1/2\pi RC$$

When $f \gg f_c$, the measured signal is directly proportional to the generated charges:

$$v(t) = -\frac{q(t)}{C}$$

When $f \ll f_c$, the measured signal is proportional to the derivate:

$$v(t) = -R \cdot \frac{dq(t)}{dt}$$

Safety and Storage

Please refer to the safety datasheet

Contact Information

Piezotech
Arkema-CRRA
Rue Henri Moissan
69496 Pierre-Benite Cedex

Info.piezotech@arkema.com

Tel : +33 4 72 39 97 03

www.piezotech.eu

Disclaimer

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, ARKEMA expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. See SDS for Health & Safety Considerations.

Arkema has implemented a Medical Policy regarding the use of Arkema products in Medical Devices applications that are in contact with the body or circulating bodily fluids (<http://www.arkema.com/en/social-responsibility/responsible-product-management/medical-device-policy/index.html>) Arkema has designated Medical grades to be used for such Medical Device applications. Products that have not been designated as Medical grades are not authorized by Arkema for use in Medical Device applications that are in contact with the body or circulating bodily fluids. In addition, Arkema strictly prohibits the use of any Arkema products in Medical Device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. The Arkema trademarks and the Arkema name shall not be used in conjunction with customers' medical devices, including without limitation, permanent or temporary implantable devices, and customers shall not represent to anyone else, that Arkema allows, endorses or permits the use of Arkema products in such medical devices.

It is the sole responsibility of the manufacturer of the medical device to determine the suitability (including biocompatibility) of all raw materials, products and components, including any medical grade Arkema products, in order to ensure that the final end-use product is safe for its end use; performs or functions as intended; and complies with all applicable legal and regulatory requirements (FDA or other national drug agencies) It is the sole responsibility of the manufacturer of the medical device to conduct all necessary tests and inspections and to evaluate the medical device under actual end-use requirements and to adequately advise and warn purchasers, users, and/or learned intermediaries (such as physicians) of pertinent risks and fulfill any postmarket surveillance obligations. Any decision regarding the appropriateness of a particular Arkema material in a particular medical device should be based on the judgment of the manufacturer, seller, the competent authority, and the treating physician. ¹